

超薄型汎用ワイヤレスキーボード

IC-BK12


日本語取扱説明書

www.iclever.com

パッケージ内容 1xワイヤレスキーボート 1xUSB充電ケーブル 1x取扱説明書 1x保証カード

Bluetoothバージョン Bluetooth 3.0 281.7 x 135 x 14 mm 通信範囲 < 10 m リチウム電池容量 280 mAh < 2 時間 連続使用時間 90 時間 90 日 裏面材質 ステンレス鋼

インジケーターについて



キーボード電源スイッチ

② 電源インジケーター:スイッチをオンにして、緑色で3秒ぐらい点灯します。 Bluetooth接続状態インジケーター: 1/2/3の機器がペアリングされた場合、①/②/③

インジケーターが青色でゆっくりと点滅します。 ③ 充電ポート

④ 充電インジケーター:充電中は赤色で点灯し、充電完了になったら消灯。 ⑤ Bluetoothペアリングボタン:「Fn+pairing」を押すと、インジケーターが青色 で点滅し、ペアリングモードに入ります。接続されると、インジケーターが

★ ユーザーへ: Caps Lockインジケーターがないですが、機能は通常通りに 使用できます。

ペアリングの手順

ステップ1. 電源スイッチをオンにして、電源インジケーターが青色で3sぐらい点 灯してから消灯します。

ステップ2. Fn+®1を押すと、®1が青色でゆっくりと点滅します。 ステップ3. 「Fn+pairing」を押すと、®1 インジケーターが青色で早いスピードで 点滅します。タブレットまたはスマートフォンでBluetoothデバイスを

ステップ4. リストにあるBluetooth「iCleverIC-BK12Luxury」をクリックして接続し

ステップ1. Fn+32を押すと、32が青色でゆっくりと点滅します。 ステップ2、「Fn+pairing」を押すと、32インジケーターが青色で速いスピードで

ステップ 5.ペアリングされた後、インジケーター 81 が青色で点灯します。

点滅します。タブレットまたはスマートフォンでBluetoothデバイスを

ステップ3. リストにあるBluetooth「iCleverIC-BK12Luxury」をクリックして接続し ステップ4. 正常にペアリングされた後、インジケータ 32 が青色に点灯します。

三台目のデバイスとペアリング

ステップ1. Fn+33 を押すと,33 が青色でゆっくりと点滅します。 ステップ2.「Fn+pairing」を押すと、83インジケーターが青色で速いスピード

ステップ3. リストにあるBluetooth「iCleverIC-BK12Luxury」をクリックして接続し

2. 自動接続機能: キーボードを開いたら、最後に使用されたデバイスと自

に従ってもう一度試してください。

ファンクションーキー機能

Windowsのタブレットでは、「Fn」を押しながらF1 \sim F12を同時に押すとファンクションキーが起動されます。

	For Android	Fn on Windows	For Win	For iOS
Esc	N/A	N/A	Esc	N/A
△	ホーム	F1	ウェブブラウザ	ホーム
Q	検索	F2	検索	検索
AII	すべて選択	F3	すべて選択	すべて選択
Q	コピー	F4	コピー	コピー
P	ペースト	F5	ペースト	ペースト
*	カット	F6	カット	カット
Id∢	曲戻し	F7	曲戻し	曲戻し
►II	再生/一時停止	F8	再生/一時停止	再生/一時停止
				•

で点滅します。タブレットまたはスマートフォンでBluetoothデバイス

ステップ4. 正常にペアリングされた後、インジケーター 33 が青色に点灯します。

1. いずれのデバイスを作動させる場合、相応なFn +</br>
1. いずれのデバイスを作動させる場合、相応なFn +
1. 下n +
2 、 Fn +
3

動的に接続します。 3. 接続失敗の場合は、デバイスからペアリング履歴を削除し、上記の手順

	For Android	Fn on Windows	For Win	For iOS
	101711101010	THOM WINGOWS	101 11111	101103
Esc	N/A	N/A	Esc	N/A
\triangle	ホーム	F1	ウェブブラウザ	ホーム
Q	検索	F2	検索	検索
AII	すべて選択	F3	すべて選択	すべて選択
Q	コピー	F4	コピー	コピー
a	ペースト	F5	ペースト	ペースト
*	カット	F6	カット	カット
I 44	曲戻し	F7	曲戻し	曲戻し
	玉井 / 吐烷.L		五井 / 陆烷上	五井 / 吐烷儿

重要事項一入力言語の設定

For iOS

曲送り

ボリュームダウン ボリュームダウン

ボリュームアップ ボリュームアップ

電源ディスプレイ 電源ディスプレイ

Shift+]

Shift+;

カタカナ ひらがな

N/A

キーボード ディスプレイ

For iOS

Next track

Volume +

Keyboard display

Power Display

N/A

Shift+] {

Shift+;

カタカナ ひらがな

ペアリング

For Win

Screenshot

ペアリング

曲送り

N/A

注意: Android、WindowsまたはiOS、各システムの間で切り替えるにはFn + Q、

Windowsのタブレットを使用する場合、日本語状態で以下の文字入力方法

Fn + Q - Android Fn + W - Windows Fn + E - iOS

Shift+9

Shift+=

Shift+\

For Android Fn on Windows

F9

▶▶I 曲送り

Prtsc N/A

Shift+8

□ ボリュームダウン F10

□+ |ボリュームアップ | F11

電源ディスプレイ

ンキーが使用できない可能性があります。

キーボード ディスプレイ

ペアリング

入力言語の切り替え

Samsung Android: shift + Space

iOS 8とそれ以前のシステム: cmd + Space

iOS 9とそれ以降のシステム: ctrl + Space

Google Android: ctrl + Space Windows: cmd + Space / ctrl+shift

Next track

Keyboard displa

Power Display

Pairing

本製品は多国言語対応であるため、使用する前に入力言語の設定が必要です。 1. iOS デバイスの場合: 設定>一般>キーボード>キーボード>新しいキーボードを追加>使いたい言語を選択

2. Samsung Androidデバイスの場合: 設定>コントロール>言語と文字入力>Samsungキーボード>入力言語を選択

> 使いたい言語を選択 3. Androidデバイスの場合:

設定>言語と文字入力> 物理キーボード>キーボードレイアウト設定>使い

4. Windowsデバイスの場合:

コントロールパネル>時間・言語・地域>使いたい言語を選択 Fn + W、またはFn + Eキーを押してください。そうしないと、一部のファンクショ

対応するシステム

・ iOS 6.0とそれ以降のシステム ・ Mac OS X v10.6 、 Mac OS X v10.12とそれ以降のシステム

・Windows XP / Vista / 7 / 8 / 10 , PC (Bluetooth機能あり)

・ Android 3.0とそれ以降のシステム(Bluetooth HID profile機能あり) ・ 当キーボードはSamsung Smart TV

(UE37ES5500,UE55KU6400U,UE48JU6400)、Mac mini、Nokiaスマホに 対応しません。

省エネモード

30分間操作しない場合、キーボードが自動的にスリープモードに入ります。 再起動するには、いずれのキーを押して、3秒ぐらいお待ちください。

1. 付属のUSBケーブルを使って充電してください。一端をパソコンやACア ダプタがに接続し、もう一端をキーボードの充電ポートに接続してくだ

2. 充電中、充電インジケーターが赤色で点灯します。フル充電まで約2時間 かかります。(入力: DC 5V/500mA)

デバイスと接続できない... 1. お使いのデバイスとキーボードのバッテリ残量が不足ではないかを確認

2. お使いのデバイスのBluetooth機能がオンになっているかを確認してく

3. お使いのデバイスとキーボードの距離を10メートル以内にしてください。

(iclever

Ultra-slim Universal Wireless Keyboard

IC-BK12

User Manual

www.iclever.com


Package Contents

- 1 x Wireless Keyboard
- 1 x USB Charging Cable 1 x Carry Pouch
- 1 x User manual 1 x Warranty Card

Specifications

Bluetooth version	Bluetooth 3.0		
Dimensions	281.7 x 135 x 14 mm/ 11.09 x 5.31x 0.55 in		
Operating Range	< 10 m / 32.8 ft		
Lithium Battery Capacity	280 mAh		
Charge time	< 2 hours		
Uninterrupted Work Time	90 hours		
Stand-by time	90 days		
Front side of keyboard	ABS		
Back side of keyboard	Stainless steel		

Indicator Lights Description



Keyboard Switch Button.

Power Switch: Lights up green for about 3s when being turned on.

Bluetooth Status Indicator: ① / ② / ③ indicator flashes in blue color when the first / second / third device is waiting for pairing .

3 Micro Charging Port: Only for charging.

4 Battery Indicator: Red light will turn on when the keyboard is charging and turns green once fully charged.

5 Bluetooth Pairing Button: Will flash blue after pressing the "Fn + pairing" Keys together. It disappears when connected.

★ For all users: No Caps Lock indicator, but will still function normally.

Pairing with the 1st device

Step 1. On the keyboard, slide the power button on. The green light will be on for 3s and

Step 2. Press Fn + §1, §1 Indicator flash blue.

Step 3. Press "Fn + pairing", §1 indicator flash blue, starting to search the available bluetooth device. Step 4. Find the Bluetooth name "iClever IC-BK12 Luxury" and click for connection.

Pairing with the 2nd device

Step 1. Press Fn + § 2, § 2 Indicator flash blue.

Step 5. The 11 indicator will be blue after successfully paired.

Step 2. Press "Fn +pairing", § 2 indicator flash blue, starting to search the available bluetooth device.

Step 3. Find the Bluetooth name "iClever IC-BK12 Luxury" and click for connection. Step 4. The § 2 indicator will be blue after successfully paired.

Pairing with the 3rd device

Step 1. Press Fn + 3 3, 3 Indicator flash blue.

Step 4. The § 3 indicator will be blue after successfully paired.

1. Three devices can be actively paired at one time, only need to press Fn+ $10^2 \$ key, changing to the accorded paired device

Keys and Functions

For the Windows tablets, press and hold the "Fn" keys while pressing the F1-F12 keys.

	For Android	Fn on Windows	For Win	For iOS
Esc	N/A	N/A	Esc	N/A
\triangle	Home	F1	Web browser	Home
Q	Search for	F2	Search for	Search for
All	Select all	F3	Select all	Select all
Q.	Сору	F4	Сору	Сору
돁	Paste	F5	Paste	Paste
*	Cut	F6	Cut	Cut
l∢∢	Previous track	F7	Previous track	Previous track
►II	Play/pause	F8	Play/pause	Play/pause

Step 2. Press "Fn + pairing", 💡 3 indicator flash blue, starting to search the available Step 3. Find the Bluetooth name "iClever IC-BK12 Luxury" and click for connection.

2. Re-connection function: Turn on the keyboard, it can connect with the last used 3. If connection is failure, delete the pairing record from your device, and try the above

system, otherwise some key's function are invalid. For the windows tablets, how to type the below letters in the status of

Shift+8 Shift + -Shift+= @

Shift+\

Shift+,

Next track

Volume -

Volume +

Screenshot

Power Display

Pairing

NOTE: After connecting with the device, your must press Fn + relative

OS key (Q for Android, W for Windows, E for iOS) to select operating

How to switch keyboard language

Samsung Android: shift + Space Google Android: ctrl + Space Windows: cmd + Space / ctrl+shift iOS 8 or below: cmd + Space iOS 9 or above: ctrl + Space

IMPORTANT

As this is a multilingual keyboard, set the language of the device to your

desired language before use. 1. For iOS devices only: Settings > General > Keyboard > Keyboards > Add new keyboard > Select

2. For Samsung Android devices only

Settings > Controls > Language and input > Samsung Keyboard > Select input languages > Select desired language

Settings > Language & input > Physical Keyboard > Set up keyboard

layouts > Select desired language

4. For Windows devices only: Control Panel > Clock, Language and Region > Select desired language

System requirements

Mac OS X v10.6 to Mac OS X v10.12 and above

 Windows XP / Vista / 7 / 8 / 10 , PC computer with a Bluetooth host Android 3.0 and above with Bluetooth HID profile (Smartphones and Tablets) • This keyboard is not compatible with Samsung Smart TV (UE37ES5500,UE55KU6400U,UE48JU6400),Mac mini and Nokia phones.

Power Saving Mode

The keyboard will enter sleep mode after being idle for 30 minutes. To activate it, press any key and wait for 3 seconds.

How to Charge it

Use the included USB cable for charging. Connect one end to a USB charger, and the other to the keyboard. (USB charger is not included)

2. In charging, the power indicator will turn red. Generally, it takes approximately 2 hours for a full charge. (Output: DC 5V/500mA)

If you are unable to connect the keyboard to your tablet, please try the

1. Starting with a full charge on both devices ensures that process won't be interrupted by a low battery

2. Check your tablet's Bluetooth is on. 3. Make sure that the keyboard is within the effective operation distance of 32.8 feet (10 m).

-12-