iclever

折りたたみ式タッチパッド付きBluetoothキーボード

IC-BK08

取扱説明書

www.iclever.co.jp

パッケージ内容

1.ワイヤレスキーボード
2. ガイドなしはがきテーブル
3.ユーザーマニュアル
4. キャリングパウチ
5.保証カード

特徴

1. Bluetooth Bluetooth 5.1プッシュを内蔵します。
2. Android、Windows、iOSシステムのタブレットまたはスマートフォンなどに対応します
3. 55.2*45.8mmマルチポイントタッチパッド機能を搭載します。
4. マクロキーの中ボタンとして使用でき、操作がエキシブルながら簡単です。
5. がり曲がりで、持ち運びに便利なデザイン。
6. 同時に3台のBluetoothデバイスと接続でき、各々間で簡単に切り替えます。
7. 充電用のmicro usb インターフェイス。
8. 充電式リチウム電池を搭載。
9. 軽量、小型、静音なタイピング。
10.スリープモードがあるから、省電力。
11.正面：プラスチック 裏面：アルミ合金。

インジケーターライト説明

- 電源インジケーター①②③：3つのインジケーターがすべて青色に点灯します。
- 充電インジケーター④：キーボードが充電中は赤色で点灯し、フル充電の場合は自動的にオフになります。
- 電源不足インジケーター⑤⑥⑦：充電中には、3つのインジケーターがすべて赤く点滅します。
- Bluetoothインジケーター①②③：1/2/3の機能がペアリングの中、青く点滅し、ペアリングできた場合は、ステータスインジケーターが青く点灯しています。
- 充電ポート④：キーボードの充電用。
- ペアリングボタン：長時間すると、Fn+Cキーを同時に押すと、①②③のインジケーターが3回に青色でゆっくりと点滅します。

ペアリング手順

一台目のデバイスのペアリング

ステップ1. キーボードを起動し、**もし②③**3インジケーターが3秒間は青色に点灯しもの後消灯します。
ステップ2. 「Fn」+ **①** キーを押すとチャンネル1に入り、インジケーターが青色で点滅します。
ステップ3. 「Fn」+「C」キーを同時に押して、**①**インジケーターが青色で点滅しペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。
ステップ4. 「Clever IC-BK08 Keyboard」という名のBluetoothキーボードをクリックして接続します。
ステップ5.接続されると、**①**インジケーターが青色に点灯します。

二台目のデバイスのペアリング

ステップ1. 「Fn」+ **②** キーを押すとチャンネル2に入り、**②**インジケーターが青色で点滅します。
ステップ2. 「Fn」+「C」キーを同時に押して、**②**インジケーターが青色で点滅しペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。
ステップ3. 「Clover IC-BK08 Keyboard」という名のBluetoothキーボードをクリックして接続します。
ステップ4. 接続されると、**②**インジケーターが青色に点灯します。

三台目のデバイスのペアリング

ステップ1. 「Fn」+ **③** キーを押すとチャンネル3に入り、**③**インジケーターが青色で点滅します。
ステップ2. 「Fn」+「C」キーを同時に押して、**③**インジケーターが青色で点滅しペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。
ステップ3. 「Clover IC-BK08 Keyboard」という名のBluetoothキーボードをクリックして接続します。
ステップ4. 接続されると、**③**インジケーターが青色に点灯します。

b.接続されたエつのデバイスを切り替えるには

「Fn」+ **①/②/③** を同時に押して切替します。

c.接続されているチャンネルを再ペアリングするにはどうしたら良いですか？

チャンネルは（または チャンネル2または3）をデバイスとして二に接続して、はかのデバイスをチャンネルとして接続したい場合、次の手順で操作してください。
ステップ1. 「Fn」+ **①** キーを押すとチャンネル1に入ります。
ステップ2. 「Fn」+「C」キーを同時に押すと、**①**インジケーターが青色で点滅しペアリングモードに入ります。デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。
ステップ3. 「Clover IC-BK08 Keyboard」という名のBluetoothキーボードをクリックして接続します。
ステップ4. 接続されると、**①**インジケーターが青色に点灯します。

ご注意:
1.異接続機能：キーボードの電源をオンにすると、最後に使用したデバイスと自動的に接続します。（接続デバイスのBluetooth機能をオンにしてください）
2.ペアリングに失敗した場合は、デバイスからペアリング履歴を削除し、上記の手順を再度試してみてください。

windows10とAndroidデバイスでは、日本語ローマ字入力のステータスにて以下の文字入力方法

Shift+	^	Shift+	&	Shift+	'	Shift+	:
Shift+	(	Shift+	)	Shift+	~	Fn+	=
Shift+	"	Shift+	~	Fn+	]	Fn+	[
Fn+	]	Shift+	@	Shift+	`	Fn+	;
Shift+	[	Shift+	{	Fn+	'	Fn+	\
Fn+	;	Shift+	+	Fn+	¥	Shift+	¥

キーボード機能

Android及びiOSのタブレットのショートカットキーを有効にするには、「ホームキーと 「Fn」キー同時に押すことより有効効果ます。
Windowsのタブレットでは、ショートカットキーと 「Fn」 + 「Shift」同時に押すことより有効効果す。

Fn+	iOS システム機能	Android システム機能	Windows システム機能
1	ペアリング	ペアリング	ペアリング
2	ブルートゥース チャンネル1	ブルートゥース チャンネル1	ブルートゥース チャンネル1
3	ブルートゥース チャンネル2	ブルートゥース チャンネル2	ブルートゥース チャンネル2
4	ブルートゥース チャンネル3	ブルートゥース チャンネル3	ブルートゥース チャンネル3
Q	検索 （機能なし in iOS 10）	検索	検索
W	戻る （機能なし in iOS 10）	戻る	戻る
E	再生／中断停止	再生／中断停止	再生／中断停止
R	進む （機能なし in iOS 10）	進む	進む
T	サイレント	サイレント	サイレント
Y	ボリュームダウン	ボリュームダウン	ボリュームダウン
U	ボリュームアップ	ボリュームアップ	ボリュームアップ
I	電池残量	電池残量	N/A
O	ロックスクリーン	ロックスクリーン	F12
P	N/A	ホーム画面	N/A
A	音量	N/A	N/A
S	ホーム画面／ スクリーンショット	ホーム画面／ スクリーンショット	ホーム画面／ スクリーンショット
D	メール	N/A	メール
F	Delete （機能なし in iOS 10）	Delete	Delete

注意:デバイスが接続された後、必ず「Fn」+「Q」/「W」/「E」を押して、相応するオペレーションシステムに切り替えられます。
（「Fn」+「Q」/「W」/「E」キーを押してiOS / Android / Windowsシステムに切り替えます）

特記事項
1.このキーボードはWindows Mobilieに対応しません。
2.Apple iOSデバイスはタッチパッドやマウス機能をサポートしません。

キーボード言語を切り替える方法

Samsung Android：Shift + Space
Google Android：Ctrl + Space
Windows：Win + Space
iOS 9以下：Win + Space
iOS 9以上：Ctrl + Space

タッチパッド機能

	Windows	Android
1本の指でクリックする	マウスの左ボタン	マウスの左ボタン
1本の指でスライドする	マウスのインタを移動する	マウスポインタを移動する
1本の指ですばやくクリックしてドラッグする	ドラッグするターゲットを選択するためのボタン	ドラッグするターゲットを選択するためのボタン
2本の指をクリックする	マウスの右ボタン	機能なし
2本の指が垂直または水平方向に移動する	垂直または水平方向にスクロールする	機能なし
2本の指が逆方向で動く	ズームインアウト	機能なし

バランススタント展開ステップ

キーボードのフックを使って、タイピング時に安定するように両側にこつの足をとります。

システム要求

- iOS 6.0以上
- Mac OS X v10.6～Mac OS X v10.12以上
- Windows XP / Vista / 7/8/10, Bluetoothホストを搭載したPCコンピュータ
- Bluetooth HIDプロファイルを搭載したAndroid 3.0以上（スマートフォンとタブレット）
- このキーボードはSamsung Smart TVと互換性がありません。（UE37ES5500, UE55KU6400U, UE48JU6400）Mac mini およびNokiaの電話機でもまれます。

省エネモード

キーボードは30分以上操作がない場合は自動的に省エネモードに入ります。
任意のキーを押して3秒後に再起動します。

充電

1.付属されるUSB充電ケーブルを使って充電してください。
ケーブルの一端をUSBチャージャーに接続し、もう一端をキーボードに接続してください（USBチャージャーは別売です）。
2.充電中、インジケーターが赤く点灯します。充電が完了するまで約2時間かかります（出力: DC 5V/500mA）

FAQ

デバイスと接続できない

以下のような手順に従って操作してください。
①Bluetooth機能がオンになっていることをご確認してください。
②デバイスのBluetooth接続記録を削除してください。
③デバイスのBluetoothをオフにした後、再度オンにして、接続見てください。
④デバイスとキーボードKB08の距離をできる限り近づけてください。
⑤キーボードKB08お使いのデバイスをフル充電してください。
⑥キーボードとデバイスを再起動してください。
注：Bluetoothのタグ字をたしてキーボードを接続していても場合、互換性の原因により部分のアプアグがキーボードと接続できない可能性があります。

日本語入力モードで入力と出力の切替点が異なる
IC-BK08キーボードは日本語（JIS）では大文字、英語（US）配列ですので、こ入力と出力の切替点が異なります。英語（US）入力モードに切り替える時、入力と出力の切替点が一致します。

一部のファンクションキーが使えません。
ファンクションキーを使用する前に、上記の「キーボード機能」をお読みください。相応するオペレーションシステムに切り替えられるかどうかを確認してください。（「Fn」と Q / W / E キーを押してiOS / Android / Windowsシステムに切り替えます）

キーボード機能

iOS キーはWindowsのWinキーまたはiOS / OS Xシステムのコマンドキーとしてどちらでも機能します。お使いのデバイスのシステムがWindowsの場合、キーはWinキーとして使用出来ます。お使いのデバイスのシステムがiOSまたはiOS X の場合、キーはコマンドキーとして使用出来ます。

安全使用するよのこ注意

1. 本製品をそれに傷をつられる長い間物から離れてください。
2. 本製品のこ濡れものを使わないでください。
3. 本製品を手入れする際、タオルなどで軽く表面を拭いてください。
4. キーボードにコーヒー、お茶または他の液体をこぼさないでください。

カスタマーサービス:

E-メール: support@iclever.co.jp

iclever

Tri-folding Wireless Keyboard with Touchpad

IC-BK08

User Manual

www.iclever.co.jp

Package Contents:

1. Foldable Wireless Keyboard
2. Ejector Material
3. USB Charging Cable
4. Carrying Bag
5. Warranty Card

Bluetooth Keyboard Characteristics:

1. Built-in USA BROADCOM Bluetooth module 5.1
2. Compatible with IOS/Android/Windows system devices
3. With multi-point touchpad function
   (not working for ipad/Macbook/etc)
4. Magnetic power on/off design, easy and flexible to operate.
5. Tri-fold design, convenient to carry.
6. Can pair with 3 Bluetooth devices simultaneously, easy to change among them.
7. MICRO USB interface, easy to charge.
8. Built-in rechargeable lithium battery.
9. Light weight, quiet keystrokes.
10. Energy saving keyboard with sleep mode.

Indicator lights description

- Power Indicator (①②③): All 3 indicators light up in blue color for 3s.
- Charging Indicator ④: It lights up in red color when the keyboard is charging and turns off once fully charged.
- Low Battery Indicator (⑤⑥⑦): All 3 indicators flash in red when it is time to recharge.
- Bluetooth Indicator (①②③): (①②③) indicator flashes in blue color when the first / second / third device is waiting for pairing and lights up blue sturdily after it has been paired successfully.
- Micro Charging Port (④): Used for charging the keyboard.
- Pairing Keys (②): After (②) combination keys being pressed together, (①②③) indicator flashes in blue color and slowly flashes 3 times for reconnecting.

Pairing Instruction:

Pairing with the 1st device

Step 1. Unfold the keyboard, **①②③**3 indicators will be on for 3 seconds.
Step 2. Press "Fn"+ "**①**" key to enter channel 1.
Step 3. Press "Fn" + "C" to enter pairing mode. Indicator will flash blue, starting to search available Bluetooth device.
Step 4. Find the Bluetooth name"iClever IC-BK08 Keyboard" and click to connect it.
Step 5. Bluetooth indicator will be blue after successfully paired.

Pairing with the 2nd device

Step 1. Press "Fn"+ "**②**" key to enter channel 2.
Step 2. Press "Fn" + "C" to enter pairing mode, Indicator will flash blue, starting to search available Bluetooth device.
Step 3. Find the Bluetooth name"iClever IC-BK08 Keyboard" and click to connect it.
Step 4. Bluetooth indicator will be blue after successfully paired.

Pairing with the 3rd device

Step 1. Press "Fn"+ "**③**" key to enter channel 3.
Step 2. Press "Fn" + "C" to enter pairing mode, Indicator will flash blue, starting to search available Bluetooth device.
Step 3. Find the Bluetooth name"iClever IC-BK08 Keyboard" and click to connect it.
Step 4. Bluetooth indicator will be blue after successfully paired.

b. How to switch among 3 devices that have already been connected?

Press "Fn"+ **①/②/③**keys to switch among connected devices.

c. How to re-pair a channel that is already connected?

If you already connect channel 1 (or channel 2 or 3) with device 1, and you want to use another device to re-pair to channel 1 (or channel 2 or 3), please do as following:
Step 1. Press "Fn"+ "**①**" keys to enter channel 1.
Step 2. Press "Fn"+"C" keys to enter pairing mode: status indicator will flash blue, starting to search the available Bluetooth device.
Step 3. Find the Bluetooth name "iClever IC-BK08 Keyboard" and click to connect it.
Step 4. Bluetooth indicator will be blue after successfully paired.

Notes.
1.Auto re-connect function, when you turn on the keyboard, it will connect with the last-used device automatically.
2. If connection fails, delete all the pairing record from your device, and follow the above instructions again.

For windows 10 device or Android devices, under Japanese input method, Romaji status, you can type these characters by below:

Shift+	^	Shift+	&	Shift+	'	Shift+	:
Shift+	(	Shift+	)	Shift+	~	Fn+	=
Shift+	"	Shift+	~	Fn+	]	Fn+	[
Fn+	]	Shift+	@	Shift+	`	Fn+	;
Shift+	[	Shift+	{	Fn+	'	Fn+	\
Fn+	;	Shift+	+	Fn+	¥	Shift+	¥

Keys and Function

For iOS (iPhone/iPad) and Android devices, press "Fn" + desired shortcut keys (F1-F12) to use shortcut functions.
For windows devices, press "Fn"+"Shift"+desired shortcut keys (F1-F12) to use shortcut functions.

Key num	iOS Function	Android function	Windows function
1	pairing	pairing	pairing
2	Bluetooth channel 1	Bluetooth channel 1	Bluetooth channel 1
3	Bluetooth channel 2	Bluetooth channel 2	Bluetooth channel 2
4	Bluetooth channel 3	Bluetooth channel 3	Bluetooth channel 3
Q	Search (N/A in iOS 10)	Search	Search
W	Back (N/A in iOS 10)	Back	Back
E	Play/pause	Play/pause	Play/pause
R	Next track	Next track	Next track
T	Mute	Mute	Mute
Y	Volume +	Volume +	Volume +
U	Volume -	Volume -	Volume -
I	Power display	Power display	Power display
O	Lock screen	Lock screen	F12
P	Home screen/ display	N/A	N/A
A	N/A	Back	N/A
S	Screen shot	Screen shot	Screen shot
D	Email	N/A	Email
F	Delete （N/A in iOS 10）	Delete	Delete

Fn+	iOS function	Android function	Windows function
1	pairing	pairing	pairing
2	Bluetooth channel 1	Bluetooth channel 1	Bluetooth channel 1
3	Bluetooth channel 2	Bluetooth channel 2	Bluetooth channel 2
4	Bluetooth channel 3	Bluetooth channel 3	Bluetooth channel 3
Q	Search (N/A in iOS 10)	Search	Brightness +
W	Back (N/A in iOS 10)	Back	Brightness -
E	Play/pause	Play/pause	Play/pause
R	Next track	Next track	Next track
T	Mute	Mute	Mute
Y	Volume +	Volume +	Volume +
U	Volume -	Volume -	Volume -
I	Power display	Power display	Power display
O	Lock screen	Lock screen	F12
P	Home screen/ display	N/A	N/A
A	N/A	Back	N/A
S	Screen shot	Screen shot	Screen shot
D	Email	N/A	Email
F	Delete （N/A in iOS 10）	Delete	Delete

NOTE: After connected with the device, your must press Fn +Q/W/E keys (Q for iOS, W for Android, E for Windows) to select corresponding operating system, otherwise some key's function are invalid.

Special Note:
1. This keyboard doesn't not support windows mobile
2. Touchpad mouse function is not working for Apple IOS devices

How to switch keyboard language
Samsung: Android: Shift +Space
Google: Android: Ctrl +Space
Windows: Win+Space
iOS 8 or below: Win+Space
iOS 9 or above: Ctrl+Space

Touchpad function

	Windows	Android
One finger click	Mouse left button	Mouse left button
Slide one finger	Move mouse pointer	Move mouse pointer
One finger quick click to hold and drag	Left button to select target to drag	Left button to select target to drag
two fingers click	Mouse right button	No function
two fingers move vertically or horizontally	vertical,horizontal scroll	No function
two fingers move	Zoom In/Out	No function

Balance Stand Opening Steps

With two foot stands on both side to keep balance and stable when typing.

System requirements

- iOS 6.0 and above
- Mac OS X v10.6 to Mac OS X v10,12 and above
- Windows XP / Vista / 7 / 8 / 10 , PC computer with a Bluetooth host
- Android 3.0 and above with Bluetooth HID profile (Smart-phones and Tablets)
- This keyboard is not compatible with Samsung Smart TV (UE37ES5500, UE55KU6400U,UE48JU6400),Mac mini and Nokia phones.

Power Saving Mode

The keyboard will enter sleep mode after being idle for 30 minutes.
To activate it, press any key and wait for 3 seconds.

How to Charge it

1. Use the included USB cable to charge. Connect one end to a USB charger, and the other to the keyboard.
(USB charger is not included)
2. In charging, the power indicator will turn red. Generally, it takes approximately 2 hours for a full charge.
(Output: DC 5V/500mA)

FAQ

My keyboard fails to connect.

If you can't successfully connect the keyboard to your device, please try as following:
① Ensure your Bluetooth function is on.
② Delete all the connection records.
③ Turn off the Bluetooth on your devices and turn it on again
④ Minimize the distance between the IC-BK08 keyboard and your device as close as possible.
⑤ Fully charge both devices to ensure the pairing process won't be affected by low batteries.
⑥ Restart the keyboard and your devices.
Note: If you connect keyboard by Bluetooth adapter, some adapters may be unable to connect because of compatibility problem.

In Japanese input method, why the punctuation of input and output is different?

This keyboard is based on US layout, not Japanese Layout; hence in Japanese input method, the punctuation will be different from English(US) input method, the punctuation will be same as English(US) input.

Why some function is not working?

Before to use function keys, please read above "Keys and Function" first; in addition, please ensure you already switch to corresponding system by pressing "Fn" and Q/W/E key switching to iOS/Android/Windows system.

What is the function of "$\frac{Fn}{Lock}$" key?

The "$\frac{Fn}{Lock}$" can work either be win in windows or Command key in iOS/OS X system, if your device system is Windows, the key will work as Win key; if your device system is IOS or OS X, the key will work as Command key.

Safety Instructions

1. Keep the keyboard away from sharp objects that could damage it.
2. Do not put heavy objects on the keyboard.
3. To clean the keyboard, gently wipe it by using a moist cotton cloth.
4. Please do not spill coffee, tea or other liquids on the keyboard.

Contact:

For more question, please free to contact us by
support@iclever.co.jp (Japan)