iclever

スタンド付きミニ折り畳みキーボード

IC-BK11

日本語取扱説明書

www.iclever.co.jp

パッケージ内容

1x折り畳みキーボード本体
1xUSB充電ケーブル
1x携帯ポーチ
1x取扱説明書
1x保証カード

仕様

Bluetoothバージョン	Bluetooth 5.1
サイズ(折り畳み時)	202.5 x 88.1 x 15.2mm
通信範囲	< 10 m
リチウム電池容量	160 mAh
充電時間	< 2 時間
連続利用時間	60時間
待受け時間	60 日
正面素材	ABS
裏面素材	アルミニウム合金

インジケーターについて



①電源／充電インジケーター
1) キーボードを開いて電源スイッチをオンにしてください。
2) インジケーターが緑色で10秒ぐらい点灯してから消灯します。
充電中：赤色で点灯します；充電完了：自動的に消灯します。
インジケーターが青色でゆっくりと点滅します。

②③④ Bluetoothインジケーター
ペアリングモード：青色で点滅します；
ペアリング完了：自動的に消灯します。

操作手順

a.ペアリング手順

一台目のデバイスのペアリング

ステップ1．キーボードを開いて、電源スイッチをオンにします。
ステップ2．「Fn」＋「Q」キーを押すとチャンネル1に入り、
状態インジケーターが素早く青色で点滅します。
ステップ3．「Fn」＋「C」ボタンを押すと、状態インジケーターが
ゆっくり青色で点滅し、ペアリングモードに入ります。
デバイスのBluetooth機能をオンにして、使用可能なデバイスを検索します。
ステップ4．「iClever IC-BK11 Keyboard」という名のBluetooth キーボードを
クリックして接続します。
ステップ5．接続されると、状態インジケーターが青色に点灯します。

二台目デバイスとペアリング

ステップ1．「Fn」＋「W」キーを押すとチャンネル2に入り、
状態インジケーターが素早く青色で点滅します。
ステップ2．「Fn」＋「C」ボタンを押すと、状態インジケーターがゆっくり
青色で点滅し、ペアリングモードに入ります。
ステップ3．画面上のデバイス名から「iClever IC-BK11 Keyboard」を
クリックして接続します。ペアリングされた後、状態インジケータが
青色に点灯します。

三台目デバイスとペアリング
「Fn」
ステップ1．「Fn」＋「E」を押すとチャンネル3に入り、状態インジケーターが
素早く青色で点滅します。
ステップ2．「Fn」＋「C」ボタンを押すと、状態インジケーターがゆっくり
青色で点滅し、ペアリングモードに入ります。
ステップ3．画面上のデバイス名から「iClever IC-BK11 Keyboard」をクリックし
て接続します。ペアリングされた後、状態インジケータが青色に
点灯します。

b. 接続された三つのデバイスを切り替えるには?

Fn+Q/W/Eを同時に押して切り替えます

c. 接続されているチャンネルを再ペアリングするにはどうしたら良いですか?

チャンネル1（またはチャンネル2または3）をデバイス1とすでに接続して、
ほかのデバイスをチャンネル1と接続したい場合、次の手順で操作してください。
ステップ1．「Fn」＋「Q」キーを押すとチャンネル1に入ります。
ステップ2．「Fn」＋「C」ボタンを押すと、状態インジケーターが青色で点滅し、
ペアリングモードに入ります。デバイスのBluetooth機能をオンにして、
使用可能なデバイスを検索します。
ステップ3．「iClever IC-BK11 Keyboard」という名のBluetoothキーボードを
クリックして接続します。
ステップ4．接続されると、状態インジケーターが青色に点灯します。

ご注意：

1. 再接続機能：キーボードの電源をオンにすると、最後に使用したデバイスと
自動的に接続します。（接続デバイスのBluetooth機能をオンにしてください）
2. ペアリングに失敗した場合は、デバイスからペアリング履歴を削除し、
上記の手順を再度試してみてください。

ショートカットキー

AndroidまたはiOSタブレットシステムの場合、ショートカットキーを有効にするには、ショートカットキーと「Fn」キー同時に押してください。
Windowsのタブレットでは、ショートカットキー＋「Fn」＋「Shift」を同時に押してください。

	Fn on Android	Fn on Windows	Fn +Shift on Windows	Fn on iOS
	ホーム	Esc	ウェブブラウザ	ホーム
	検索	F1	検索	検索
	すべて選択	F2	すべて選択	すべて選択
	コピー	F3	コピー	コピー
	ペースト	F4	ペースト	ペースト
	カット	F5	カット	カット
	バック	F6	N/A	N/A
	曲戻し	F7	曲戻し	曲戻し
	再生／一時停止	F8	再生／一時停止	再生／一時停止
	曲送り	F9	曲送り	曲送り
	ボリュームダウン	F10	ボリュームダウン	ボリュームダウン
	ボリュームアップ	F11	ボリュームアップ	ボリュームアップ
	電池残量	電池残量	N/A	電池残量

注意: Android,WindowsまたはiOS,各システムの間に切り替えるにはFn + A, Fn + S, またはFn + Dキーを同時に押してください。そうしないと、一部のファンクションキーが使えません。

Fn +A - Android　　Fn + S – Windows　　Fn + D – iOS

windows10とAndroidデバイスでは、日本語ローマ字入力のステータスに以下の文字入力方法

Shift+	0 @ P `	“	Shift+	6 ^ N ~	&	Shift+	7 ' F '	‘
Shift+	8 * M :	(	Shift+	9) N]	)	Shift+	- = ^ ¥	=
Fn+	U ↑ . [	～	Fn+	I ↑ ,]	∧	Fn+	O ↑ ; [	}
Fn+	P ↑ ;]	]		↑ ^ @	@	Shift+	↑ ^ @	＼
Fn+	K ↑ , \	*	Fn+	L ↑ . ;	:	Shift+	↑ . ;	+
	↑ ↑ ↑ [	[	Shift+	↑ ↑ ↑ [	{			

スタンドについて

スタンドにはマートフォン以外のデバイスを乗せないでください。重量の重いタブレットなどを載せると故障の原因になります。

シリコンパッド

デスクトップと直接接続することを防ぎ、製品を傷つけないように使用されます。
使い方はキーボードの裏側に8個のシリコンパッドを貼り付けます。

省電力スタンバイモード

30分間操作しない場合、キーボードがスタンバイモードに入ります。
キーボードを再起動するには、いずれのキーを押して、3秒間くらいお待ちください。

充電について

1. 付属されるUSB充電ケーブルを使って充電してください。
2. 充電中、電源／充電インジケーターが赤く点灯します。フル充電まで約二時間が必要です。（出力：DC 5V/500mA）

FAQ

デバイスと接続できない
以下のような手順に従って操作してください。
①Bluetooth機能がオンになっていることをご確認してください。
②デバイスのBluetooth接続記録を削除してください。
③デバイスのBluetoothをオフにした後、再度オンにして、接続見てください。
④デバイスとキーボードBK11の距離をできる限り近づけてください。
⑤キーボードとデバイスをフル充電してください。
⑥キーボードとデバイスを再起動してください。
注： Bluetoothアダプタを介してキーボードを接続している場合、互換性の問題により部分のアダプタがキーボードと接続できない可能性があります。

日本語入力モードで、入力と出力の句読点が異なる
IC-BK11キーボードは日本語（JIS）ではなく、英語（US）配列ですので、
入力と出力の句読点が異なります。英語（US）入力モードに切り替える時、
入力と出力の句読点が一致します。

一部のファンクションキーが使えません
ファンクションキーを使用する前に、上記の「キーボード機能」を
お読みください。相応するオペレーションシステムに切り替えられる
かどうかを確認してください。（「Fn」と A/S / D キーを押して
Android / Windows / iOSシステムに切り替えます）

iclever

Mini Foldable Keyboard with Hideable Stand

IC-BK11

User Manual

www.iclever.co.jp

Package Contents

1 x Foldable Keyboard
1 x USB Charging Cable
1 x Carry Pouch
1 x User manual
1 x Warranty Card
8 x Silicone Pad

Specifications

Bluetooth version	Bluetooth 5.1
Dimensions	202.5 x 88.1 x 15.2mm / 7.97 x 3.47x 0.6 in
Operating Range	< 10 m / 32.8 ft
Lithium Battery Capacity	160 mAh
Charge time	< 2 hours
Uninterrupted Work Time	60 hours
Stand-by time	60 days
Front side of keyboard	ABS
Back side of keyboard	Aluminum alloy

Indicator Lights Description



① **Power indicator:** The light turns green for 10s when power switch is on.
Charging indicator: Red light will be stably on when charging it, and it automatically turns off after being fully charged.

② ③ ④ **Bluetooth indicator:** Blue lights blinking quickly while waiting for pairing. Turn blue if pair successfully.

Operation Instruction

a. How to pair with wireless devices?

Pairing with the 1st device

Step 1. On the keyboard, slide the power button to on., the status indicator will be green for 10s then be off.
Step 2. Press "Fn"+"Q" keys to enter channel 1, the status indicator flash blue.
Step 3. Press "Fn"+"C" keys to enter pairing mode, the status indicator will flash blue slowly.
Step 4. Find the Bluetooth name "iClever IC-BK11 Keyboard" and click to connect it. The status indicator will be blue after successfully paired.

Pairing with the 2nd device

Step 1. Press "Fn"+"W" keys to enter channel 2, the status indicator flash blue.
Step 2. Press "Fn"+"C" keys to enter pairing mode; the status indicator will flash blue slowly.
Step 3. Find the Bluetooth name "iClever IC-BK11 Keyboard" and click to connect it. The status indicator will be blue after successfully paired.

Pairing with the 3rd device

Step 1. Press "Fn"+"E" keys to enter channel 3, the status indicator flash blue.
Step 2. Press "Fn"+"C" keys to enter pairing mode, the status indicator will flash blue slowly.
Step 3. Find the Bluetooth name "iClever IC-BK11 Keyboard" and click to connect it. The status indicator will be blue after successfully paired.

b. How to switch among 3 devices that have already been connected?

Press "Fn" and "Q" / "W" / "E" keys to switch among connected devices.

c. How to re-pair a channel that has already been connected?

If you already connect channel 1 (or channel 2 or 3) with device 1, and you want to use another device to connect channel 1 (or channel 2 or 3), please do as following.
Step 1. Press "Fn"+"Q" keys to enter channel 1, the status indicator flash blue.
Step 2. Press "Fn"+"C" keys to enter pairing mode, the status indicator will flash blue slowly.
Step 3. Find the Bluetooth name "iClever IC-BK11 Keyboard" and click to connect it. The status indicator will be blue after successfully paired.

Notes:

1. Auto re-connect function. when you turn on the keyboard, it will connect with the last-used device automatically.
2. If connection fails, delete all the pairing record from your device, and follow the above instructions again.

Keys and Functions

To use the shortcut keys, hold the "Fn" key while pressing the desired shortcut key on the Android or iOS tablets.
For the Windows tablets, press and hold the "Fn" + "Shift" keys while pressing the desired function keys.

Key icon	Fn on Android	Fn on Windows	Fn +Shift on Windows	Fn on iOS
	Home	Esc	Web Browser	Home
	Search for	F1	Search for	Search for
	Select all	F2	Select all	Select all
	Copy	F3	Copy	Copy

	Paste	F4	Paste	Paste
	Cut	F5	Cut	Cut
	Back	F6	N/A	N/A
	Previous track	F7	Previous track	Previous track
	Play/pause	F8	Play/pause	Play/pause
	Next track	F9	Next track	Next track
	Volume down	F10	Volume down	Volume down
	Volume up	F11	Volume up	Volume up
	Power Display	Power Display	N/A	Power Display

NOTE:
After connecting with the device, your must press Fn + relative OS key (A for Android, S for Windows, D for iOS) to select operating system, otherwise some key's function are invalid.

For windows 10 device or Android devices, under Japanese input method, Romaji status, you can type these characters by below:

Shift+	0 @ P `	“	Shift+	6 ^ N ~	&	Shift+	7 ' F '	‘	
Shift+	8 * M :	(	Shift+	9) N]	)	Shift+	- = ^ ¥	=	
Fn+	U ↑ . [	～	Fn+	I ↑ ,]	∧	Fn+	O ↑ ; [	}	
Fn+	P ↑ ;]	]		↑ ^ @	@	Shift+	↑ ^ @	＼	
Fn+	K ↑ , \	*	Fn+	L ↑ . ;	:	Shift+	↑ . ;	+	
	↑ ↑ ↑ [	[	Shift+	↑ ↑ ↑ [	{				

Hidden Holder Stands

With two hideable and rotatable stands, ONLY for holding the smartphones.

Silicone pad

It is used for avoiding the touch between keyboard and desk to damage the keyboard. To use it by adding 8 silicone pads at the back side of keyboard.

Power Saving Mode

The keyboard will enter sleep mode after being idle for 30 minutes.
To activate it, press any key and wait for 3 seconds.

How to Charge it

1. Use the included USB cable for charging. Connect one end to a USB charger, and the other to the keyboard. **(USB charger is not included)**
2. In charging, the power indicator will turn red. Generally, it takes approximately 2 hours for a full charge. (Output: DC 5V/500mA)

FAQ

My keyboard fails to connect.

If you can't successfully connect the keyboard to your device, please try as following:
① Ensure your Bluetooth function is on.
② Delete all the connection records.
③ Turn off the Bluetooth on your devices and turn it again
④ Minimize the distance between the IC-BK11 keyboard and your device as close as possible.
⑤ Fully charge both devices to ensure the pairing process won't be affected by low batteries.
⑥ Restart the keyboard and your devices.

Note:
if you connect keyboard by Bluetooth adapter, some adapter may be unable to connect because of compatibility problem.

In Japanese input method, why the punctuation of input and output is different?

This keyboard is based on US layout, not Japanese Layout; hence in Japanese input method, the punctuation will be different. When you switch to English(US) input method, the punctuation will be same as layout.

Why some function is not working?

Before to use function keys, please read above "Keys and Function"first; in addition, please ensure you have already switched to corresponding system by pressing "Fn" + "A"/ "S"/ "D" keys (A for Android, S for Windows , D for iOS) switching to Android/Windows/ iOS system.